




User Manual

WS-2391



Thank you for purchasing the **Sami wearable WS-2391 GPS5 SMARTWATCH** Read the instructions carefully to obtain optimum results and preserve it for future reference.




CONTENTS.

Wearable, USB magnetic charging cable, instruction manual.

CHARGING

Connect the device to a computer or laptop with the USB Magnetic cable for charging. Put in contact the magnetic end of the USB cable with the charging points positioned in the back of your device. Kindly use only the USB cable included with the wearable. If you use a power adapter for charging, the output of the power adapter should be 5V, 1A. Charging time: 1-2 hours approx. Please charge the device fully before using it. Take care with the magnet side of the cable, if you connect to the AC and you have contact with a metal surface, you may damage the charging cable



Button①definition:

Power button

Short press: Short press once on the watch face interface to turn off the screen. Short press once on the application list interface to return to the watch face interface. Short press once again to turn off the screen.

Long press for 2s: power on/off, restart, SOS (long press to display menu selection).

Press and hold for 12 seconds: force restart the device.

Button②definition:

Return key/shortcut key:

Short press:

A. Other pages return to the previous level/customized shortcut functions.

B. Short press while the screen is idle to light up the screen.

C. Pause/continue during exercise.

D. Short press when there is an incoming call to mute.

Press and hold for 2 seconds: Open the voice assistant/custom shortcut function.

Supplement: Customers can choose one of the return key/shortcut key. If the shortcut function is not set, short press to return to the previous level, and long press the voice assistant. If the shortcut function is set, follow the setting items to achieve it.

Definition of button③(sports button):

Short press:

A. Enter the sports mode list

B. Short press to light up the screen when the screen is off

C. Long press for 2S during sports; stop and end the sports

GETTING STARTED:

- APP Download

1) How to obtain the BT Connection APP / APK (**GloryFit Pro**)

Search for the **GloryFit Pro APP** in the Play Store for Android devices; download it and install it in your Android smartphone, or go to our **website www.sami.es** and download the application.

For Iphone, search **GloryFit Pro** in App Store and download to proceed installation on your device.

2) Installation of the **GloryFit Pro** APP

When installing the **GloryFit Pro** application on your smartphone, you must allow all the Application Permissions, allow this **GloryFit Pro** app auto run.

The first time you run this **GloryFit Pro app**, it will ask you to Enable Notifications, please tap OK and tap the **GloryFit Pro** and confirm OK. You must tap OK/Allow/Pair/Yes/Confirm for any pop-up request. On your smartphone permission management, allow all application permissions.

3) How to make the wearable pair with your smart phone?

*First, turn on the Bluetooth of your Phone.

*Second, run the **GloryFit Pro** app on your Phone, on the home page of **GloryFit Pro**, find the pairing request by the setting all your values requested and then select “**watch**”. You must have the screen of the watch on and the APP will search for new Bluetooth device(s), when the available Bluetooth device displays, please select **WS-2391** (the BT name of this device). Select the device on the app to make it pair. When you pair for the first time, the **GloryFit Pro** app will ask you to enable GPS and Bluetooth, and authorize **GloryFit Pro** to get access to the location service while using the app. Please accept all the requests for the correct functioning of the device. When you finish select OK/Confirm/Allow for any pop-up request.

Important: To enable all notifications of different softwares such as WhatsApp, Facebook, Skype, Twitter, you will need to turn on the notifications on the APP manually. On the **Fitcloud Pro** homepage, select the icon “**Device**” (situated on the right bottom of the screen), → select “**WS-2391**” → select “**message notification**” → turn on “**Allow notification**” and turn on all the APP notifications you want to active.

1. TOUCH SCREEN CONTROL DEFINITIONS

On the watch face interface, press and hold the watch face for 2-3 seconds to switch watch faces. Swipe left or right to switch watch faces, and click to select a watch face.

Swipe down: Swipe down on the watch

face interface to open the status bar

Swipe up: Swipe up on the watch face interface

to access the card shortcut function

Swipe left: Swipe left on the watch face

interface to enter the main menu interface

Swipe right: Swipe right on the watch face interface

to enter the notification information interface



4. GPS USAGE


1. In order to get a better experience, please connect and bind the APP when using the GPS function for the first time. Within about 3 minutes after binding, the "GloryFitPro" app will send GPS ephemeris orbit and other data to the watch via Bluetooth in the background. After the ephemeris is successfully sent, the GPS positioning time can be greatly shortened. If the sending is not successful, the watch will pop up the "AGPS has expired" reminder when you open the sports with GPS function for the first time. AGPS expiration will cause the positioning time to be too long, affecting the positioning experience. You can try to unbind and bind the watch APP again. And wait for 2 minutes before trying to use the GPS function. If APGS is sent successfully, the "AGPS has expired" reminder will not pop up when you open the GPS function for the first time.

2. At 09:00 every morning, the "GloryFitPro" app will re-acquire the latest GPS ephemeris data of the day. The watch obtains the latest GPS ephemeris data when Bluetooth is connected.

3. The GPS positioning time is too long and whether the GPS track drifts are greatly affected by environmental factors. Choosing an open place or away from high-rise buildings will help GPS to quickly locate and reduce the deviation of the track.

4. Save the data after the exercise, and the APP will synchronize the exercise data. The exercise trajectory and exercise data can be queried in detail on the APP.


5. GPS USAGE INTERFACE



AGPS has expired No Location Get Location Sports with location

During the connection process, a pop-up window will pop up to confirm the pairing connection with the watch and mobile phone. Please click to confirm the pairing.

After the connection is successful, the call icon and data connection icon in the watch status bar will turn green. In gray, it is not connected.



BT Call and APP Disconnected APP Connected BT Call Disconnected APP Connected BT Call Connected

TECHNICAL SPECIFICATIONS:

Display screen: AMOLED screen 1.43". Full colour touch screen

Screen resolution: 466x466pixels.

Internal Memory: 256mb

MCU Chipset: ATS3085L

Acceleration and gyroscopes: STK821

Heart rate sensor: VC30F

Charge port : USB magnetic charging cable

Battery: Built in Li-Polymer 500mAh

Stand by time: 15-20 DAYS

Working time: 7-10 DAYS

Bluetooth: BLE 5.3

Water-resist Rating: 5ATM this device resists 50 meters waterproof (5ATM). Not valid for hot water shower due to vapor.

Weight: 85g silicone strap

Declaration of Conformity

Hereby we,

Name of manufacturer: SANTOSHI SL
Address: CALLE FELIPE ASENJO N.56
Zip code & City: 28947 - FUENLABRADA (MADRID)
Country: SPAIN

declare that this DoC is issued under our sole responsibility and that this product:

Product description: Smart Watch
Type designation(s): WS-2391
Trademark: SAMI WEARABLE

is in conformity with the relevant Union harmonization legislation:

DIRECTIVE EMC 2014/30/EU

DIRECTIVE LVD 2014/35/EU

Standard CE (RED): DIRECTIVE 2014/53/EU

Standard RoHS: 2011/65/EU: (RoHS) Restriction of Hazardous Substance.

with reference to the following standards applied:

EN 60950-1: 2006+A11:2009+A1:2010+A12:2011+A2:2013

EN 62479:2010

EN 301 489-1 V2.1.1 (2017-02)

EN 301 489-17 V3.1.1 (2017-02)

EN 300 328 V2.1.1 (2016-11)



Signature

Full name: VISHAL MIRPURI

Position: ADMINISTRATOR

Date: 07/11/2024

Contact support: info@sami.es