

# Sami<sup>®</sup>

## WEARABLE

Instruction Manual  
Model: WS-2302

Thank you for purchasing the **Sami** wearable WS-2302. Read the instructions carefully to obtain optimum results and preserve it for future references.

### MAIN FEATURES:



1. Compatible with Android/iPhone.



2. This wearable can be paired to your smart phone by Bluetooth. The version of the Bluetooth is V 3.0.



3. The wearable can be used in vibration mode.



4. The WS-2302 has a built in microphone to answer calls.



5. The speaker of the wearable permits you to listen to music and hear incoming calls.



6. Supports multiple languages .



7. Phone book. You can access the phone list of your smart phone through your wearable.



8. Hands free.



9. You can make and receive telephone calls with the help of your wearable.



10. Identification of incoming calls.



11. Anti lost function 15m.



12. You can read your messages on the display.



13. Permits you to check Whatsapp or any PUSH messages.



14. Allows you to check Facebook notifications.



15. Built in alarm clock.



16. Built in altimeter.



17. Built in barometer.



18. Calculator.



19. Calendar.



20. Stopwatch.



21. Pedometer.



22. Music playing.

### HOW TO OBTAIN THE REQUIRED APPLICATION:

- Before you use your Sami wearable please open the following link [www.sami.es/smartwatchWS2302](http://www.sami.es/smartwatchWS2302)

**Note:** This application is only operative with Android devices. The IOS devices have limited functions and the connect to your wearable only by Bluetooth.

- Or if you have the QR code reader already installed on your smart phone scan the below code



### FUNCTION AND KEY DESCRIPTION:

- Power/home button: Long press to switch on/off the smart watch and short press to return to the stand by screen.
- Back/return /end call: Click in this icon to return to the previous menu or to end a call.
- Volume: Click on the pop-up volume control icon to regulate volume levels.
- Confirm/answer: When in the stand by screen, click on this icon to confirm the required option of the main menu and is also used to answer incoming phone calls.
- Microphone: The buit in microphone allows to speak. Ensure that it is not blocked or covered while speaking.
- Micro USB port: Charge your wearable connecting it to your computer by means of the USB cable (included).
- Speaker: The built in speaker allows you to listen to music and in normal mode hear incoming telephone calls. Like the built in mic, make sure the speaker is not covered.
- Reset hole: This can be find on the back of the watch. To access the reset button, insert a pointed instrument in the reset hole in order to reset the system.

### MAIN MENU DESCRIPTIONS (TOTAL FIVE PAGES ON THE INTERFACE OF DISPLAY SCREEN)

- Page 1: Bluetooth, Phone book, dial-up, messaging.
- Page 2: Call history, remote notifications, Bluetooth music, remote camera.
- Page 3: Barometer, altimeter, pedometer, stopwatch.
- Page 4: Profiles, settings, burglar alarm, calendar.

· Page 5: Calculator, alarm, style choice.

**Bluetooth pairing and synchronizing :** Once the required application has been successfully installed you can connect your wearable and synchronize it with your mobile via Bluetooth. Activate the Bluetooth function on your mobile. Initiate search for device, and when WS-2302 appears on the screen, select the device and pair it with your wearable.

· Phone book. After synchronizing the wearable you will be able to access the phone book of your mobile through the watch. Hence you can make and receive calls.

· Dial-up: It will be activated when the wearable connects with the smart phone via Bluetooth.

· Message: The watch allows you to read your messages from the inbox and also shows you the sms that has been sent.

· Call history: This feature shows the following menu:

1. Missed calls-shows the calls not answered on the phone and allows you to call this contact.
2. Dialed-displays the numbers dialed and allows you to call any contact.
3. Receive calls: Shows the calls answered and allows to call this contact.
4. All calls.

· Bluetooth music: You can enjoy listening to music (stored on the mobile) through your smart watch by means of Bluetooth.

· Remote notifications. Push notifications and Whatsapp: The smart watch informs you about Whatsapp and Facebook notifications. This feature requires you to install the APK "BT Notification. apk" on your android smart phone. The wearable will ring/vibrate to notify new messages.

· Remote camera. You can access the camera of your mobile from your wearable.

· Barometer. This feature displays the current atmospheric pressure and current temperature.

· Altimeter. This feature has the following menu:

1. Relative height. It shows the vertical height from a particular point.
2. Altitude. Refers to the vertical height of a location about the sea floor.
3. Advance. Once the relative height of the current location has been calculated, set the starting point to zero, to calculate the relative height of another location.
4. Reset. Reset the relative height of 0 m .

· Pedometer. This feature calculates the time required to reach the pre-determined target (hours, minutes, seconds) and number of miles/km. When this feature is selected you will see the following menu:

1. Pedometer-index menu press the start time and it displays the number of steps and calories index.
2. Gender. Select man or woman.
3. Height. Set height (cm)
4. Weight. Set weight (kg).
5. Step. Set step size (cm).

· Stopwatch. To calculate elapsed time.

· Scenario mode. In this feature you will see the follow menu:

1. Normal mode-the standard ring mode.
2. Silent mode-no sound mode.
3. Meeting mode-vibration mode.
4. Outdoor mode.

· Calendar: Displays the date.

· Burglar alarm/anti-lost. When the watch is more than 15 m away from the mobile, it vibrates to inform the wearer that the two devices are not close-by. This is helpful to prevent loss or theft of the mobile. (Ensure that this function is activated).

· Settings. In this feature you will see the following menu:

1. Time and date settings. Allows you to set the date and time.
2. Language. Allows you to choose the language you prefer.
3. Stand-menu settings. Allows you to choose between the different analog and digital clock wallpaper options, lock screen settings.
4. Other settings. You can set the LCD backlight brightness and the backlight of stand by time.

· Calculator.

· Alarm.

· Style selector. There are three different styles to choose from the menu interface.

**· Warning: Between the two operative systems android and iOS, there is a possibility that some of the features of the wearable do not function as they should with the iOS. It is important to mention that smartphones use different versions of the android operation system and there is a probability that all the features of the wearable may not function optimally.**

#### **TECHNICAL SPECIFICATIONS:**

**Display screen: Touch screen TFT 1.44".**

**Screen resolution: 128x128 pixels.**

**Internal memory: 128 Mbit+64 Mbit (Nor Flash SRAM)**

**Audio decode: AMR, AAC, MP3, MIDI.**

**Video decode: MP4, 3GP.**

**Image decode: JPEG.**

**Charge I/O port: Micro USB 5 pin.**

**Battery: Built in Li-Polymer 230 mAh**

**Stand by time: 160 hours**

**Bluetooth talk time: 3h**

**Music playing time: 6 h**