
Sami[®]

WEARABLE

User Manual

WS-2372

JUNIOR TECH



Thank you for purchasing the Sami wearable WS-2372. Read the instructions carefully to obtain optimum results and preserve it for future reference. Sami has developed wearable devices since 2015 and we use the best components possible for the product.


1. Quick start guide

Overview



1. Touch screen
2. Heart sensor
3. Charging PIN

- Make sure the pins on the charging cable fit correctly onto the charging terminals on the back of your smart watch.
- Plug the big end of the USB cable to a power source and after successful charging, a charging icon will appear on the screen.



Install “Fit4Kid” app on the phone

Search and install the “Fit4Kid” app from Google Play or App Store. Or scan the following QR code to install the app directly.



Connect the smart watch with the phone

1. Enable Bluetooth on your smart phone.
2. Open the “Fit4Kid” app on your smart phone, and then fill in all the requested information in the “Settings” menu.
3. Tap “Connect device” in the “Settings” menu.
4. Select the smart watch icon to connect.
5. Choose your device name to connect it with your phone.

-
6. Please note that you must connect through the app and not by the bluetooth menu of your phone.
 7. You will see pop up windows of permissions while installing, please accept all of them for the correct functioning specially referred to location and background execution.

Unbind smart watch with mobile phone

1. Open “Fit4Kid” app on your smart phone.
2. Tap “Disconnect device” in the “Settings” menu and confirm “OK”.
3. To disconnect your smart watch with a Phone, click “Disconnect device” in the “Settings” menu of “Fit4Kid” app, and go to the Bluetooth settings on your Phone, then access and select “Forget This Device”.

Operation Introduction


- To switch on the watch, press and hold the center of the touch screen until the display is on.
- To switch off the watch, slide the screen from right to left on main interface to enter in sub-menu, and then slide the screen up and down to enter in settings, you will find power off icon there.
- You can press the touch screen, or turn on gesture control in advanced settings of Fit4Kid and then raise your hand to light the screen.

2. How to use

- **Turn on:** Press and hold the center of the touch screen for 3 seconds.
- **Go to main menu:** Slide from right to left on main interface; slide up and down to check more functions
- **Select a function:** Slide up and down; tap the icon.
- **Confirm:** Tap the icon.
- **Exit menu:** Slide from left to right on the screen.
- **Check notifications:** Slide from left to right on main interface.




3. Main menu



After turning on the smart watch, the main interface will be displayed.

From the main interface:


1. Go to the main menu
 - a. Slide from right to left to enter the main menu.
 - b. Slide up and down to check more functions.
 - c. Tap the icon to enter the sub menu. Slide from left to right to return to the previous menu.



2. Go to the notification shortcut interface
Slide from left to right from the main interface.



3. Go to other shortcuts screen
Slide up and down from the main interface.



No. 1 Brightness

You can adjust screen brightness by click this icon.

No. 2 Find phone

When your smart watch is connected with Fit4Kid, you phone will ring by click this icon.

No. 3 Shut down

You can shut down your smart watch by click this icon.

No. 4 About

You will find name, address, and firmware version by click this icon.

4. Functions


Watch faces



There are 3 watch faces. In current watch face, press and


hold the center of the touch screen to choose the one you like.

Daily activities



The watch will record your daily activity automatically. Press the step icon to check pedometer, distance and calories. After synchronizing with APP, these sports data can be also checked in APP.


Heart rate monitor


Select the  heart rate icon to monitor your current heart rate. To exit the heart rate monitor, please slide to right.




If you've connected your smart watch with APP via Bluetooth, you can also check your heart rate data in the app.

Multi-Sport



Tap the  sport icon to enter the multi-sport mode. The smart watch has 4 sports modes: walking, running, hiking, and cycling. Choose a sport mode you want, and then do sports. The smart watch will record your exercise data.




If you want to end the sports, slide the screen to right and tap the stop icon to finish your sports and save the data. The smart watch displays your exercise data after that. If you've connected your smart watch with Fit4Kid via Bluetooth, you can also check your exercise data in the app.



Note: if the exercise time is less than 5 minutes, the data cannot be saved.




Sleep monitor



The smart watch automatically monitors your sleep from 10p.m. to 9a.m.

When you get up the next day, the smart watch displays your sleep report about the time of total sleep, light sleep and deep sleep. If you've connected your smart watch with APP via Bluetooth, you can also check more detailed sleep report in the app.


Weather




If you've connected your smart watch with Fit4Kid via Bluetooth, the smart watch will display the weather forecast.


You can manually set the city or automatically set a city in APP.

Alarm



By tapping the  alarm icon, you can see the alarm timer you've set in APP. When alarm time is up, the alarm icon will be animated and the smart watch will vibrate.

Notification



Slide the watch face from left to right, and then you can check your phone calls, SMS, QQ, WeChat, Whatsapp, Facebook and Twitter notifications, etc.

Remote capture




To use this feature, make sure the camera of your smart phone is on. With the remote capture function, you can


take pictures remotely from your smart watch.

Music playback control




Tap the  music icon to enter the music playback control interface.

You can select the previous/next song, and play/pause music. To exit music playback control, slide the screen from left to right.




Stopwatch

Press Start to time ,To exit Stopwatch, slide the screen from left to right.




Sedentary




Tap the  icon to enter the sedentary settings. You can turn the function on or off. Slide the screen to right to exit. You can also go to the “Activity&Wellness” under

the “Health Reminder” of APP to set the time intervals (minutes), start time and end time.




Children games



Tap this icon to enter the watch game function


Pedometer



Tap this icon to enter the Pedometer game. Completing the corresponding steps will show different characters


Math






Tap this icon to enter the Math game. Each correct answer is 10 points. If you collect 100 points, you will pass the game.


Puzzle



Tap this icon to enter the Puzzle game, enter the game and the final rendering will appear. Tap 9 pictures on the screen to start the game randomly. Tap the picture next to the space to swap positions with the space. After the puzzle is completed, it will enter the next puzzle.

Settings



Tap the  icon to enter the settings menu

- About



Tap this icon to check the Bluetooth Mac address, device name and firmware version of your smart watch.

- Reset



Tap this icon to reset your smart watch.

- Restart





Tap this icon to restart your smart watch.

● Shut down



Tap this icon to shut down your smart watch.

****** THIS IS NOT A MEDICAL INSTRUMENT, SO THE VALUES
ARE APPROXIMATE**

CLEANING:

In order to avoid any damage on the plating or printing of your wearable please do not use any chemical product for cleaning such as alcohol 96°. We recommend you to use a slightly wet cloth.

TECHNICAL SPECIFICATIONS:

Display screen: Full screen capacitive touch screen 1.30".

Screen resolution: 240 x 240 pixels.

Internal Memory: 32k RAM ROM 512k

CPU: Pixart PAR2860QN

Charge I/O port : USB magnetic charging cable

Battery: Built in Li-Polymer 150 mAh

Stand by time: 10-12 DAYS

Working time: 3-5 DAYS

G-Sensor: SC7A20

Health Sensor: HRS3301

Bluetooth: v5.1

Water-resist Rating: IP67 (raindrop resistance. This device is not waterproof; do not drown it into water)

Weight: 45 g

Declaration of Conformity

Hereby we,

Name of

manufacturer:

SANTOSHI SL

Address:

CALLE FELIPE ASENJO N.56

Zip code & City:

28947 - FUENLABRADA (MADRID)

Country:

SPAIN

declare that this DoC is issued under our sole responsibility and that this product:

Product description:

Smart Band

Type designation(s):

WS-2372

Trademark:

SAMI WEARABLE

is in conformity with the relevant Union harmonization legislation:

DIRECTIVE EMC 2014/30/EU

DIRECTIVE LVD 2014/35/EU

Standard CE (RED): DIRECTIVE 2014/53/EU

Standard RoHS: 2011/65/EU: (RoHS) Restriction of Hazardous Substance.

with reference to the following standards applied:

EN 60950-1:

2006+A11:2009+A1:2010+A12:2011+A2:2013

EN 62479:2010

EN 301 489-1 V2.1.1 (2017-02)

EN 301 489-17 V3.1.1 (2017-02)

EN 300 328 V2.1.1 (2016-11)



Signature

Full name: VISHAL MIRPURI

Position: ADMINISTRATOR

Date: 21 / 11 / 2022