

# Sami<sup>®</sup>

## WEARABLE User Manual WS-2315

Thank you for purchasing the **Sami** wearable WS-2315. Read the instructions carefully to obtain optimum results and preserve it for future reference.

### DESCRIPTION OF THE WEARABLE.



### CONTENTS.

Wearable, USB clip cable, instruction manual.

### CHARGING.

Connect the device to a computer or laptop via USB cable for charging. Insert the charging thimbles of the clip into the charging points positioned in the back of your device. Kindly use only the USB cable included with the wearable. If you use a power adapter for charging, the output of the power adapter should be 5V, 1A. Charging time: 2 hours. Please charge the device fully before using.



### HOW TO POWER ON / POWER OFF?

- 1) To turn ON the smart watch, on the screen, long touch the fixed-point for a few seconds, then raise your finger to make it Power On. The fixed-point is located on the bottom of the screen.
- 2) To turn OFF the smart watch, tap to enter into the last page of the interface where the power icon displays, long touch the fixed-point for a few seconds, raise your finger when the ON/OFF menu displays, and then quickly tap to select the OFF option, once the OFF option is selected, long touch the fixed-point for a few seconds to make it power off.

### GETTING STARTED:

#### - For Android

1) How to obtain the BT Connection APK (**FITCLOUD**)

Search for the **FITCLOUD APP** at Google Play; download it and install it in your Android smartphone.

2) Installation of the **FITCLOUD** APK.

When installing the **FITCLOUD** application on your Android, you must allow all the Application Permissions, allow this **FITCLOUD** app auto run.

The first time you run this **FITCLOUD**, it will ask you to Enable Notifications, please tap OK and tap the **FITCLOUD** and confirm OK. You must tap OK/Allow for any pop-up request. On your Android permission management, allow all application permissions.

3) How to make the wearable pair with your Android smart phone?

\*First, turn on the Bluetooth of your Phone.

\*Second, run the **FITCLOUD** app on your Phone, on the home page of **FITCLOUD**, tap "Settings" → tap "**Bind Device**" →, the APP will search for new Bluetooth device(s), when the available Bluetooth device displays, please tap **C92** (the BT name of this device) to make it pair. The pairing will be finished in a few seconds.

\* You must tap OK/Confirm for any pop-up request

**Important:** To enable all notifications of different software such as WhatsApp, Facebook, Skype, Twitter, you will need to turn on the notification on the APP manually. It may not automatically turn on.

#### - For iPhone

1) How to obtain the BT Connection APP? (**FITCLOUD**)

On iPhone, please go to APP Store and search **FITCLOUD** and install the app.

2) How to make the wearable pair with your iPhone?

\*First, turn on both the Bluetooth of iPhone

\* Run the **FITCLOUD** app on the iPhone, on the home page of **FITCLOUD**, tap "Settings" → tap "**Device**" →, the APP will search for new Bluetooth device(s), when the available Bluetooth device displays, please tap **C92**(the BT name of this device) to make it pair. The pairing will be finished in a few seconds.

You must tap OK/Confirm for any pop-up request

**Important:** To enable all notifications of different software such as WhatsApp, Facebook, Skype, Twitter, you will need to turn on the notification on the APP manually. It may not automatically turn on.

#### HOW TO CONTROL?

Once the device is connected to the app successfully it will record and analyze your activities. Please tap to slide on the screen of the device to switch between different display modes

In normal mode long press the fixed-point to activate the different functions of your device.

**Note:** To run the Heart Rate monitor/Blood Pressure Test/Blood Oxygen Test, on the FITCLOUD APP/APK, tap "Health"→ tap "Start". Slide left/right to select between Heart Rate monitor/Blood Pressure Test/Blood Oxygen Test.

#### PRODUCT FEATURES.

##### BLUETOOTH (V 4.0)

##### FIXED-POINT TOUCH CONTROL

Tap to select & view functions, or tap to select to Power On/Power OFF.

**TOUCH SCREEN.** Fixed-point touch screen 0.96"

##### BUILT IN VIBRATING MOTOR

##### BUILD IN HEART RATE SENSOR

##### BUILD IN GRAVITY SENSOR

##### DISPLAY SCREEN INTERFACE

- 1) Time/Date/Battery status/Bluetooth status displaying
- 2) Steps (Pedometer)
- 3) Calories (Pedometer)
- 4) Distance (Pedometer)
- 5) Sleep monitor
- 6) Heart rate monitor
- 7) Blood Oxygen test(SPO2)
- 8) Blood Pressure test
- 9) Messages
- 10) Looking for phone
- 11) Power Off

Data can be sync from the wearable to the smart phone on the **FITCLOUD** APK/APP.  
Your smart phone will synchronize when the Bluetooth is paired with this device.

## FUNCTIONS

**PHONE CALL NOTIFICATION** - vibrating reminder for incoming phone calls

**MESSAGE NOTIFICATION** - vibrating reminder for incoming messages, including SMS, WhatsApp, Facebook, Twitter, Skype messages, etc.

**SPORT** (MULTIPLE SPORT MODES including Running, Swimming, Basketball, Badminton.)

**PEDOMETER** (steps, distance, calories)

**HEART RATE MONITOR**

**BLOOD PRESSURE TEST**

**SLEEP MONITOR** - supported on the **FITCLOUD** APK/APP

**SEDENTARY REMINDER**(Do some exercise) - supported on the **FITCLOUD** APK/APP

**ALARM CLOCK** - supported on the **FITCLOUD** APK/APP

**GESTURE CONTROL TO LIGHT UP THE SCREEN** – you need to make the setting in the APP. (tap the paired device name and then turn on the wrist sense)

**GESTURE CONTROL TO TAKE PHOTO**(Shake to Photograph) – You may need to make the setting at the FITCLOUD APK/APP

Note: To refresh the data of the FITCLOUD APK/APP, on the FITCLOUD APP/APK, tap and slide down the screen of your phone.

## TECHNICAL SPECIFICATIONS:

**Display screen:** Capacitive touch screen IPS 0.96".

**Charge I/O port :** USB clip charging.

**Battery:** Built in Li-Polymer 90 mAh

**Stand by time:** 10 DAYS

**Working time:** 5 DAYS

**Bluetooth:** V4.0.

**Multiple Languages**

**WATERPROOF RATING: IP68 (WATERPROOF FOR POOLS OF COLD WATER, NOT SCUBA DIVING)**



# Declaration of Conformity

Hereby we,

Name of manufacturer: SANTOSHI SL  
Address: CALLE FELIPE ASENJO N.56  
Zip code & City: 28947 - FUENLABRADA ( MADRID )  
Country: SPAIN

declare that this DoC is issued under our sole responsibility and that this product:

Product description: Smart watch  
Type designation(s): WS-2315  
Trademark: SAMI WEARABLE

is in conformity with the relevant Union harmonization legislation:

**DIRECTIVE EMC 2014/30/EU**  
**DIRECTIVE LVD 2014/35/EU**

**Standard CE-RED: DIRECTIVE 2014/53/EU**  
**Standard ROHS: 2011/65/EC: restriction of dangerous substances.**

with reference to the following standards applied:

EN60950-1/A2:2013  
EN300328v1.8.1  
EN301489-1v1.9.2  
EN62479:2010  
EN301489-1 V1.9.2 (2011-09)  
EN301489-7 V1.3.1 (2005-11)  
EN301489-17 V2.2.1 (2012-09)



Signature

Full name: VISHAL MIRPURI

Position: ADMINISTRATOR

Date: 10 / 04 / 2018