

# Sami<sup>®</sup>

WEARABLE  
User Manual  
WS-2325

## SPORT

\*\*\* SMART BAND \*\*\*

Thank you for purchasing the **Sami** wearable WS-2325. Read the instructions carefully to obtain optimum results and preserve it for future reference.

### DESCRIPTION OF THE WEARABLE.



### CONTENTS.

Wearable, USB clip charging cable, instruction manual.

### CHARGING.

Connect the device to a computer or laptop with the USB clip charging cable. Insert the charging thimbles of the clip into the charging points positioned in the back of your device. Kindly use only the USB cable included with the wearable. If you use a power adapter for charging, the output of the power adapter should be 5V, 1 A. Charging time: 2 hours. Please charge the device fully before using it.



### HOW TO POWER ON / POWER OFF?

- 1) To turn ON the smart band, long press the touch button for a few seconds. The touch button is situated on the bottom of the screen.
- 2) To turn OFF the smart band, tap the touch button until you get in the Power-off interface, then long press the touch button and then select YES, and long press the touch button to make it Power off.

### HOW TO CONTROL?

- 1) On the display screen, short press the touch button control to change between the different menus. Long press to achieve the different functions.

## GETTING STARTED:

### - For Android

1) How to obtain the BT Connection APK (**WEARHEALTH**)

Search for the **WEARHEALTH APP** in the Google Play Store; download it and install it in your Android smartphone, or go to our **website [www.sami.es](http://www.sami.es)** and download the application.

2) Installation of the **WEARHEALTH** APK.

When installing the **WEARHEALTH** application on your Android, you must allow all the Application Permissions, allow this **WEARHEALTH** app auto run.

The first time you run this **WEARHEALTH**, it will ask you to Enable Notifications, please tap OK and tap the **WEARHEALTH** and confirm OK. You must tap OK/Allow for any pop-up request. On your Android permission management, allow all application permissions.

3) How to make the wearable pair with your Android smart phone?

\*Firstly, turn on the Bluetooth of your Phone.

\*Secondly, run the **WEARHEALTH** app on your Phone, on the home page of **WEARHEALTH**, select "**Mine**", →select "**Connect a device**", the APP will search for new Bluetooth device(s), when the available Bluetooth device displays, please select **Q66 or WS-2325** (the BT name of this device) to make it pair. The pairing will be finished in few seconds. When you pair for the first time, the app WEARHEALTH will ask you to fill some personal information such as gender/age/height/weight. When you finish select OK/Confirm/Allow for any pop-up request.

**Important:** To enable all notifications of Call remind, SMS remind, and more reminders of different soft wares such as WhatsApp, Facebook, Skype, Twitter, you will need to turn on the notifications on the APP manually. On the home page of WEARHEALTH, select the icon "**Mine**" (situated on the right bottom of the screen), → and select "**Device management**", → "**more reminders**", and turn on all the APP notifications you want to active.

### - For iPhone

1) How to obtain the BT Connection APP? (**WEARHEALTH**)

On iPhone, please go to the APP Store and search **WEARHEALTH** and install the app.

2) How to make the wearable pair with your iPhone?

\*Firstly, turn on the Bluetooth of iPhone

\*Secondly, run the **WEARHEALTH** app on your Phone, on the home page of **WEARHEALTH**, select "**Mine**", → select "**Connect a device**", the APP will search for new Bluetooth device(s), when the available Bluetooth device displays, please select **Q66 or WS-2325** (the BT name of this device) to make it pair. The pairing will be finished in few seconds. When you pair for the first time, the app WEARHEALTH will ask you to fill some personal information such as gender/age/height/weight. When you finish select OK/Confirm/Allow for any pop-up request.

\* Now you can start using your desired functions of the smart band.

**Important:** To enable all notifications of Call remind, SMS remind, and more reminders of different soft wares such as WhatsApp, Facebook, Skype, Twitter, you will need to turn on the notifications on the APP manually. On the home page of WEARHEALTH, select the icon "**Mine**" (situated on the right bottom of the screen), → and select "**Device management**", → "**more reminders**", and turn on all the APP notifications you want to active.

## PRODUCT FEATURES

### BLUETOOTH (V 4.0)

### TOUCH BUTTON

**TOUCH SCREEN.** Capacitive touch screen 0.96"

### BUILT IN VIBRATING MOTOR

### BUILT IN HEART RATE SENSOR

### BUILT IN GRAVITY SENSOR

### GESTURE CONTROL TO LIGHT UP THE DISPLAY SCREEN

## DISPLAY SCREEN INTERFACE

- 1) Time/Date/Battery
- 2) Steps (Pedometer)
- 3) Calories (Pedometer)
- 4) Distance (Pedometer)
- 5) Heart rate monitor
- 6) Blood pressure test
- 7) Sleep monitor
- 8) Messages
- 9) Sports Mode – Different sport modes including Walking / Running /Bicycle /Swimming /Football
- 10)Stopwatch
- 11)Find my phone
- 12)Power off

Data can be sync from the wearable to the smart phone on the **WEARHEALTH** APK/APP.  
Your smart phone will be synchronized when the Bluetooth is paired with this device.

## FUNCTIONS

**PHONE CALL NOTIFICATION** - vibrating reminder for incoming phone calls. This function need to be turned on manually at the **WEARHEALTH** APK/APP.

**MESSAGE NOTIFICATION** - vibrating reminder for incoming messages, including SMS, WhatsApp, Facebook, Twitter, Skype messages, etc. This function needs to be turned on manually at the **WEARHEALTH** APK/APP.

**CLOCK SCREENS** – (Different home digital clocks) – In the home screen of the smart band, long press the touch button for a few seconds to change the style of the digital clock.

**SLEEP MONITOR** - builded-in

**ALARM CLOCK** - supported on the **WEARHEALTH** APK/APP

**FIND THE DEVICE** – find my smart band

**PHOTOGRAPH** - (remote control your smartphone's camera.)

## STOPWATCH

**SEDENTARY REMIDER(REMINDS YOU TO MOVE)** - supported on the **WEARHEALTH** APK/APP

**METTING REMIDER** - supported on the **WEARHEALTH** APK/APP

**DRINK REMIDER** - supported on the **WEARHEALTH** APK/AP

**GESTURE CONTROL** ( Raise your hand to light up the screen)

**GPS MAP TRACE** (view it on the BT APP/APK **WEARHEALTH**). On the home page of the WEARHEALTH, tap in the **Sport** icon to view the GPS map. On the home page of the WEARHEALTH, tap in the **Sport** icon, then select the icon situated in the right, top to view the GPS map trace history record.

## MULTIPLE LANGUAGES

### TECHNICAL SPECIFICATIONS:

**Display screen:** Fixed-point capacitive touch screen 0.96".

**Screen resolution:** 80x160 pixels.

**Internal Memory:** RAM 128KB, ROM 32Mbit

**System:** Nucleus

**CPU:** NRF52832

**Charge I/O port :** USB Clip charging cable

**Battery:** Built in Li-Polymer 90 mAh

**Stand by time:** 15~20 DAYS

**Working time:** 5 DAYS

**Bluetooth:** 4.0.

**Water-resist Rating:** IP67 (this device resists raindrops, **it's not water proof**)

**Weight:** 25.2 g

**Exterior Dimensions:** 250x20x11mm

# Declaration of Conformity

Hereby we,

Name of manufacturer: SANTOSHI SL  
Address: CALLE FELIPE ASENJO N.56  
Zip code & City: 28947 - FUENLABRADA ( MADRID )  
Country: SPAIN

declare that this DoC is issued under our sole responsibility and that this product:

Product description: Smart Band  
Type designation(s): WS-2325  
Trademark: SAMI WEARABLE

is in conformity with the relevant Union harmonization legislation:

**DIRECTIVE EMC 2014/30/EU**  
**DIRECTIVE LVD 2014/35/EU**

**Standard CE (RED): DIRECTIVE 2014/53/EU**  
**Standard RoHS: 2011/65/EU: (RoHS) Restriction of Hazardous Substance.**

with reference to the following standards applied:

EN 60950-1: 2006+A11:2009+A1:2010+A12:2011+A2:2013  
EN 62479:2010  
EN 301 489-1 V2.1.1 (2017-02)  
EN 301 489-17 V3.1.1 (2017-02)  
EN 300 328 V2.1.1 (2016-11)  
 



Signature

Full name: VISHAL MIRPURI

Position: ADMINISTRATOR

Date: 17 / 09 / 2019